


Walkezee[©]


The WALKEZEE is simple to fit and simple to use,
Just follow the instructions below and start
walking your dog with 'ease'.

The WALKEZEE is simple to fit and simple to use, just follow the instructions below and start walking your dog with 'ease'.

1. Place your harness on the floor with the girth strap (main strap with fixings) in a horizontal position and the chest strap laying in a Semi-circle.



2. Place your dogs front legs into the semi-circle and pull the girth strap up onto the dogs back and fasten so that it is firm and secure.



3. Attach the collar strap to the dogs collar, looping it over and fastening back onto the velcro, ensuring that the chest strap is around your dogs chest and remains loose.

4. Using the adjusters on the Main Strap tighten so it is firm but comfortable around tummy.

5. The Chest Strap must be situated around the widest part of the chest making sure it does not restrict the leg movement.

6. Attach your lead to the O-Ring on the Chest Strap nearest to you when walking your dog(s).

7. Alternatively, attach the coupling accessory, by clipping the spring clips to the 'O' rings on either end of the Chest Strap so it is on the back of the dog and then attach your lead to the 'D' ring at the end. The Coupling Attachment is available from WALKEZEE on request.

8. For the safety of your dog WALKEZEE recommend you remove the harness when it is not attached to a lead. This can prevent your dog from becoming caught on objects. This applies to all collars.

We hope you and your dog enjoy using WALKEZEE.

Any questions, problems or general feedback telephone: 01844 353233

Walkezee holds no responsibility for any damage or injury to life or property as a result of employing the harness in any situation.